







Console KABOOK SYMBOLS




Key & Pad



Pedals



One text page




Sound



Line of text




Audio File




Down-load

State



Adjust




Search




Action

Kabook States




Playing: Console Starts mp3



PLAY mp3

Paused




789
456
123
0

mp3 frame
file 6

TAB
DEL
PU
PD
ARROWS

Lang
en de ...



Pause

espeak
volume


master
volume

-
+
/
*
•


MENU 1

Arrows
read info
Dot reads
help


- / +




Text Reader - Part 1




Text Reader - Part 2



Text Reader - Part 3



Text Enter



- AU +

- AL
- AR
- DEL
- BackSp
- END
- INS
- PU
- HOME
- AU
- AD
- PD

Cut first word
Cut last word
Cut first Char.
Cut last Char.
Trim tr. Space


insert, toggle, read:
Old line a
mp3 name
mp3 frame
system date
special characters


Read line

Read item

Spell line

Read help





Menu 3 Bookmark utility

MENU 1

MENU 2

MENU 3

0 - - -

789
456
123
0

0 - 8 -

+ m2

m2 - 8 -

+ m2 /file.mp3

m2 - 8 -

+ m2 http://

m2 - 8 -


PU
/
*

Dot
reads
help
for
menu 2

MENU 4

PLAY mp3

Menu 4 Keyboard tutor



Time-out
any
key
except

_ / +

Espeak
reads
key
name

Will read
Ctrl DEL
Alt DEL

Shift
Lock keys
PtScreen
Pause
Ctrl Alt